



OCF Snoot

Mounting instruction



About OCF Snoot

The OCF Snoot is a compact and portable Light Shaping Tool that drastically reduces the light spread from your off-camera flash.

The effect is a crisp and direct light with almost no spill light. The light has a beautiful, round shape, which can be used as hair light or any other application when only a small area needs to be illuminated.

The OCF Snoot is incredibly easy to use. You just snap it on the front of your Profoto Off-Camera Flash, and in a fraction of a second, you are good to go.

The OCF Snoot is made of a strong glass fiber that makes it lightweight and extremely durable.

Learn how to mount your OCF Snoot fast and easy and how to combine it with other OCF Light Shaping Tools in this quick guide.



- 1 Mount the OCF Snoot on your Profoto Off-Camera Flash. Press to make sure it is in place.



- 2 Now the OCF Snoot is ready to be used.

How to combine the OCF Snoot with the OCF Grids and Gels



- 1 Align the Profoto labels of the OCF Snoot and the OCF Grid&GelHolder with the grid and/or gel already mounted.
- 2 Mount the OCF Snoot on top of the OCF Grid&GelHolder. Then mount it on your Profoto Off-Camera Flash.

Attention

This product may only be used with Profoto Off-Camera Flashes that have a LED modeling light.

Follow the instructions to avoid jamming your fingers.

**For more information and inspiration:
profoto.com/offcameraflash**